Important Note: In this new version of the demixing example the names of the scripts have been changed to better reflect what they are doing. The new names are given below

- demixing.py \Rightarrow shiftphasecenter.py
- $demixing1.py \Rightarrow demixing.py$
- demixing2.py \Rightarrow subtract_from_averaged.py

1 Instructions

Here follow the step by step instructions for demixing a dataset

- 1. use LofIm
- $2.\,$ Edit NDPPP. parset Autoweight should be on, remove unwanted channels and preflag.

```
msin = L23145_SB030_uv.MS
msin.autoweight = True
msin.startchan = 2
msin.nchan = 60
msout = L23145_SB030_HydA.MS
steps = [preflag1]
preflag1.type=preflagger
preflag1.corrtype=auto
```

- 3. run NDPPP
- 4. Edit shiftphasecenter.py

The target list contains tuples with (name, ra, dec), where ra and dec are in radians.

- Run the shiftphasecenter.py script python shiftphasecenter.py
- $6. \ \ Average the three measurement sets L23145_SB030_CasA.MS, L23145_SB030_CygA.MS \\ and L23145_SB030_HydA.MS with NDPPP by editing NDPPP_avg_HydA.parset$

```
msin = L23145_SB030_HydA.MS
msout = L23145_SB030_HydA_avg.MS
steps = [avg]
```

python demixing.py

9. Run BBS on the demixed measurement sets L23145_SB030_CasA_avg_dem.MS L23145_SB030_CygA_avg_dem.MS The data will be calibrated and predicted data will be put in the MODEL_DATA column.

```
makevds <clusterdesc> L23145_SB030_CasA_avg.MS CasA.vds
makevds <clusterdesc> L23145_SB030_CygA_avg.MS CygA.vds
combinevds CasaA.gds CasA.vds
combinevds CygA.gds CygA.vds
calibrate -f --cluster-desc <clusterdesc> --db ldb001 --db-user <username>
        CasA.gds bbs_CasA.parset Ateam_LBA_CC_CasCyg.skymodel $PWD
calibrate -f --cluster-desc <clusterdesc> --db ldb001 --db-user <username>
        CygA.gds bbs_CygA.parset Ateam_LBA_CC_CasCyg.skymodel $PWD
```

10. Subtract the predicted data of the off axis sources from the averaged data of the target field. Edit subtract_from_averaged.py

- # The averaged data, including the contribution of other sources
 msname = 'L23145_SB030_HydA_avg.MS'
- # Name of the table containing the mixing matrix
 mixingname = 'mixing'
- # Names of the measurement sets with predicted data in the MODEL_DATA column
- $\ensuremath{\mathtt{\#}}$ The predicted data is going to be subtracted from the averaged data

11. Run subtract_from_averaged.py

```
python subtract_from_averaged.py
```

A new measurement set will be created with the name L23145_SB030_HydA_sub.MS

12. Calibrate the Hydra A measurement set

13. Before imaging transfer covariance information to the WEIGHT column

python covariance2weight.py L23145_SB030_HydA_sub.MS